
















T2T-CMxBPMT - Vertical Mount - Butted Panels - Mitred Tracks	SECTION B	SYSTEM PARTS		OPTIONAL PARTS
				
ELEVATION A				
	<p>SYSTEM HEIGHT (S/H) ADJUSTMENT (+/-) 1/4"</p> <p>PANEL HEIGHT = S/H-3"</p>			
SEE INSTALLATION INSTRUCTIONS FOR CORNER DETAILS				
PROJECT:		* FLOOR POST		CARRIER POST
ARCHITECT:				
<div>  <div> ALLIANCE GLASS DOORS INC. Surrey, BC, Canada, V3W 1A2 T: 604.501.2588 F: 604.501.1608 </div> </div>				
SHEET:	JOB #:	DRAWN BY: JL	DATE: 11/08/20	CHECKED BY: DL
PLEASE NOTE: "x" in the product code refers to the stile options - Standard  = "T" ;  = "214" ;  = "M58"				

Riviera Glass Divider "Collector Blocks" are designed to assist in closing multi-panel sets of sliding door panels by collecting each panel they pass by. When closing the set, the outermost panel will inter-lock with the next panel, and pull it along to its resting position. To re-open, with all required and recommended blocks installed, pushing the outermost panel will collect all panels as a group. Panels will be staggered in the fully open position.

Below you'll find instructions for installing the blocks. Pay close attention to identify your track series (Monaco or Savona), and the correct location and orientation on the panel. Peel and stick the block in place as illustrated, then install self tapping screws to permanently secure. Pre-drilling is not necessary.

IMPORTANT: Read these instructions completely before beginning any installation.

Block Location







Panel 3 collects Panel 2, Panel 2 collects Panel 1 and pulls them all to a completely closed position.



Block Orientation MONACO




LONG EDGE of Block
Flush with end of Rail
@ Bottom of Rail




SHORT EDGE of Block
Flush with end of Rail
LONG EDGE @ Bottom
of Rail




Block Orientation SAVONA



BREAK OFF BLOCK ENDS
to 3/8" x 3/8" then install
Flush with end of Rail
Bottom of Block @ bottom
of Rail... SHIM PANEL 3 ONLY



BREAK OFF at notches
to yield 2 Collector blocks
(discard middle section)



SHORT EDGE of Block
Flush with end of Rail
LONG EDGE @ Bottom
of Rail... SHIM PANEL 3 ONLY

