T2T-CMxMPxMT - Vertical Mount - Mitred Panels - Mitred Tracks

ELEVATION A

SEE INSTALLATION INSTRUCTIONS FOR CORNER DETAILS

PROJECT:

ARCHITECT:

Riviera
rivieraglassdividers.com

ALLIANCE GLASS DOORS INC.
Surrey, BC, Canada, V3W 1A2
T: 604.501.2588
F: 604.501.1608

SECTION B

MONACO Mx-TCP* with Mx-TCP* at 90°

Triple Track - Vertical Mount - Floor Post with Carrier Post to Triple Track - Vertical Mount - Floor Post with Carrier Post

SHEET:

JOB #:

SYSTEM PARTS

CUSHION CAPTURE ROLLER ASSEMBLY
(SHOWN WITH SINGLE TOP TRACK)

SYSTEM 214 2-1/4" WIDE STILE ONLY

* FLOOR POST

2 X

CARRIER POST

OPTIONAL PARTS

❒

BLACK ANODIZED FINISH

❒

SINGLE TRACK END CAP

❒

SYSTEM 214 LOCK

❒

SYSTEM 214 EDGE PULL

STANDARD INSERTS

- ❒ DIFFUSED WHITE LAMI GLASS
- ❒ CLEAR LAMINATED GLASS
- ❒ MIRROR
- ❒ PREFINISHED HARDBOARD
- ❒ MIRROR / HARDBOARD

SPECIAL INSERTS

- ❒ POLAR WHITE GLASS
- ❒ BLACK GLASS
- ❒ CUSTOMER SUPPLIED INSERT
- ❒ DIVISION BARS

DRAWN BY: JL

DATE: 11/08/20

CHECKED BY: DL

PLEASE NOTE: "x" in the product code refers to the stile options - Standard T LINE = "T" ; SYSTEM 214 = "214" MODERNO = "M58"

Monaco - System Components

1 - Main Track
2 - Snap on Fascia
3 - Fixed Lite End Cap
4 - Cushion Capture
5 - Roller
6 - Roller Bumper
7 - Adjusting Bolt
8 - Hanger Lock
9 - Rail Cap
10 - Floor Post
11 - Carrier Post

General

A - "T" Stile
B - Moderno 58 with D Shaped Pull **
C - System 214 Wide 2 1/4" Stile **
D - Sidelite Shoe
E - System 214 Lock
F - System 214 Edge Pull
G - Fixed Lite Receptor

Riviera
rivieraglassdividers.com

COLLECTOR BLOCK INSTALLATION

Riviera Glass Divider "Collector Blocks" are designed to assist in closing multi-panel sets of sliding door panels by collecting each panel they pass by. When closing the set, the outermost panel will inter-lock with the next panel, and pull it along to its resting position. To re-open, with all required and recommended blocks installed, pushing the outermost panel will collect all panels as a group. Panels will be staggered in the fully open position.

Below you'll find instructions for installing the blocks. Pay close attention to identify your track series (Monaco or Savona), and the correct location and orientation on the panel. Peel and stick the block in place as illustrated, then install self tapping screws to permanently secure. Pre-drilling is not necessary.

IMPORTANT: Read these instructions completely before beginning any installation.

Block Location

Panel 3 collects Panel 2, Panel 2 collects Panel 1 and pulls them all to a completely closed position.

Block Orientation MONACO

LONG EDGE of Block
Flush with end of Rail
@ Bottom of Rail

SHORT EDGE of Block
Flush with end of Rail
LONG EDGE @ Bottom
of Rail

Block Orientation SAVONA

T LINE

MODERNO 58

BREAK OFF BLOCK ENDS
to 3/8" x 3/8" then install
Flush with end of Rail
Bottom of Block @ bottom
of Rail... SHIM PANEL 3 ONLY

BREAK OFF at notches
to yield 2 Collector blocks
(discard middle section)

SYSTEM 214

SHORT EDGE of Block
Flush with end of Rail
LONG EDGE @ Bottom
of Rail... SHIM PANEL 3 ONLY