S2D-CMxBPxMT - Vertical Mount - Butted Panels - Mitred Tracks

ELEVATION A

SEE INSTALLATION INSTRUCTIONS FOR CORNER DETAILS

PROJECT:

ARCHITECT:

Riviera
rivieraglassdividers.com

ALLIANCE GLASS DOORS INC.
Surrey, BC, Canada, V3W 1A2
T: 604.501.2588
F: 604.501.1608

SECTION B

MONACO Mx-DCP* with Mx-SCP at 90˚

Double Track - Vertical Mount - Fixed Shoe to Double Track - Vertical Mount Floor Postwith Carrier Post

SHEET:

JOB #:

SYSTEM PARTS

CUSHION CAPTURE ROLLER ASSEMBLY
(SHOWN WITH SINGLE TOP TRACK)

T LINE STANDARD STILE

MODERNO 58

5/8" WIDE STILE WITH D-PULL

SIDELITE SHOE

CARRIER POST

* FLOOR POST

STANDARD INSERTS

- ❒ DIFFUSED WHITE LAMI GLASS
- ❒ CLEAR LAMINATED GLASS
- ❒ MIRROR
- ❒ PREFINISHED HARDBOARD
- ❒ MIRROR / HARDBOARD

OPTIONAL PARTS

❒

BLACK ANODIZED FINISH

❒

SINGLE TRACK END CAP

❒

SYSTEM 214 2-1/4" WIDE STILE

❒

SYSTEM 214 LOCK

❒

SYSTEM 214 EDGE PULL

SPECIAL INSERTS

- ❒ POLAR WHITE GLASS
- ❒ BLACK GLASS
- ❒ CUSTOMER SUPPLIED INSERT
- ❒ DIVISION BARS

DRAWN BY: JL

DATE: 08/11/25

CHECKED BY: DL

PLEASE NOTE: "x" in the product code refers to the stile options - Standard T LINE = "T" ; SYSTEM 214 = "214" MODERNO = "M58"

The sidelite shoe (shown here in red) slots into the track in the fixedlite receptor below. The bottom rail of the panel fits over and down to sit directly on sidelite shoe by adjusting the top rollers. Cushion Capture stops in the top track are then pushed tight against the top rollers to eliminate panel travel.

Optional silicone sealant may be applied to the three aluminum componets at the floor.

FIG.1 - FLUSH MOUNT

FIG. 2 - SURFACE MOUNT

5/16" high fixedlite receptor must be installed on a firm surface using construction adhesive.

It can be installed:

1) Flush in the floor (FIG. 1)

2) On the floor surface (FIG. 2)

An endcap to cover the shoe and receptor will be provided.

Monaco - System Components

1 - Main Track
2 - Snap on Fascia
3 - Fixed Lite End Cap
4 - Cushion Capture
5 - Roller
6 - Roller Bumper
7 - Adjusting Bolt
8 - Hanger Lock
9 - Rail Cap
10 - Floor Post
11 - Carrier Post

General

A - "T" Stile
B - Moderno 58 with D Shaped Pull **
C - System 214 Wide 2 1/4" Stile **
D - Sidelite Shoe
E - System 214 Lock
F - System 214 Edge Pull
G - Fixed Lite Receptor