








<p>T2T-CMxBPxBT - Vertical Mount - Butted Panels - Butted Tracks</p>	<p>SECTION B</p>	<p>SYSTEM PARTS</p>	<p>OPTIONAL PARTS</p>
 <p>ELEVATION A</p>	 <p>SYSTEM HEIGHT (S/H) ADJUSTMENT (+/-) 1/4"</p> <p>PANEL HEIGHT = S/H-3"</p>	 <p>CUSHION CAPTURE ROLLER ASSEMBLY (SHOWN WITH SINGLE TOP TRACK)</p> <p>SNAP-ON FASCIA</p>	 <p>BLACK ANODIZED FINISH</p> <p>SINGLE TRACK END CAP</p>
 <p>SEE INSTALLATION INSTRUCTIONS FOR CORNER DETAILS</p>	<p>MONACO Mx-TCP* with Mx-TCP* at 90°</p> <p>Triple Track - Vertical Mount - Floor Post with Carrier Post to Triple Track - Vertical Mount - Floor Post with Carrier Post</p>	 <p>STANDARD STILE</p> <p>5/8" WIDE STILE WITH D-PULL</p> <p>2 X</p> <p>CARRIER POST</p> <p>STANDARD INSERTS</p> <ul style="list-style-type: none"> <input type="checkbox"/> DIFFUSED WHITE LAMI GLASS <input type="checkbox"/> CLEAR LAMINATED GLASS <input type="checkbox"/> MIRROR <input type="checkbox"/> PREFINISHED HARDBOARD <input type="checkbox"/> MIRROR / HARDBOARD 	 <p>2-1/4" WIDE STILE</p> <p>LOCK</p> <p>EDGE PULL</p> <p>SPECIAL INSERTS</p> <ul style="list-style-type: none"> <input type="checkbox"/> POLAR WHITE GLASS <input type="checkbox"/> BLACK GLASS <input type="checkbox"/> CUSTOMER SUPPLIED INSERT <input type="checkbox"/> DIVISION BARS
<p>PROJECT:</p> <p>ARCHITECT:</p> <p>Riviera rivieraglassdividers.com</p> <p>ALLIANCE GLASS DOORS INC. Surrey, BC, Canada, V3W 1A2 T: 604.501.2588 F: 604.501.1608</p>	<p>SHEET:</p> <p>JOB #:</p>	<p>DRAWN BY: JL</p> <p>DATE: 11/08/20</p>	<p>CHECKED BY: DL</p>


PLEASE NOTE: "x" in the product code refers to the stile options - Standard LINE = "T" ; SYSTEM 214 = "214" ; MODERNO 58 = "M58"

Riviera Glass Divider "Collector Blocks" are designed to assist in closing multi-panel sets of sliding door panels by collecting each panel they pass by. When closing the set, the outermost panel will inter-lock with the next panel, and pull it along to its resting position. To re-open, with all required and recommended blocks installed, pushing the outermost panel will collect all panels as a group. Panels will be staggered in the fully open position.

Below you'll find instructions for installing the blocks. Pay close attention to identify your track series (Monaco or Savona), and the correct location and orientation on the panel. Peel and stick the block in place as illustrated, then install self tapping screws to permanently secure. Pre-drilling is not necessary.

IMPORTANT: Read these instructions completely before beginning any installation.

Block Location







Panel 3 collects Panel 2, Panel 2 collects Panel 1 and pulls them all to a completely closed position.



Block Orientation MONACO




LONG EDGE of Block
Flush with end of Rail
@ Bottom of Rail




SHORT EDGE of Block
Flush with end of Rail
LONG EDGE @ Bottom
of Rail




Block Orientation SAVONA



BREAK OFF BLOCK ENDS
to 3/8" x 3/8" then install
Flush with end of Rail
Bottom of Block @ bottom
of Rail... SHIM PANEL 3 ONLY



BREAK OFF at notches
to yield 2 Collector blocks
(discard middle section)



SHORT EDGE of Block
Flush with end of Rail
LONG EDGE @ Bottom
of Rail... SHIM PANEL 3 ONLY

